



## INSTALLATION GUIDE

### SHOWER CURTAIN ROD

#### 浴簾桿組安裝說明

1. Using the wall **Brackets** as a template, mark mounting hole centers on desired position, using a 6mm drill-bit, drill the holes at marked positions, then insert the **Plastic Anchors** flush with the wall. Note: The **Set-Screw** hole position on **Bracket** has been designed fit at the top as Fig# 1.

用固定基座在預定安裝的位置，畫上鑽孔的記號。使用 6 mm 鑽頭鑽孔，嵌入塑膠塞並使之齊平於牆面。如 Fig.① 所示。  
注意：固定基座上的埋頭螺絲孔須朝上方。

2. The **Rod** can be cut to the required in length. Carefully cut the **Rod** 1 cm (0.4") shorter than the distance between the fixing surfaces as Fig# 2.

浴簾桿可依所須安裝的長度裁剪，裁剪長度須較測量牆面的距離短少一公分，如 Fig.② 所示。

3. Ensure that the **Bracket-Covers** and the **Brackets** are placed onto the **Rod** in the correct orientation before install, then fix the assembly's **Brackets** to the wall, slide **Bracket-Covers** over the **Brackets** and secure the **Bracket-Covers** in place by tightening the **Set-Screws** through the **Bracket** top holes.

確認浴簾桿依照安裝順序，穿過兩個裝飾蓋與兩個固定基座，然後以螺絲鎖緊固定基座於牆面上，將裝飾蓋套上固定基座，用隨附的六角板手將埋頭螺絲穿過固定基座上方的埋頭螺絲孔，鎖緊於浴簾桿，即完成安裝程序。

## FIXING CONTENTS

#### 組配件內容

<p>Ⓐ <b>Bracket</b> × 2 固定基座</p>	<p>Ⓑ <b>Bracket-Cover</b> × 2 裝飾蓋</p>	<p>Ⓒ <b>Rod</b> × 1 浴簾桿</p>	<p>Ⓓ <b>Set Screw</b> × 2 埋頭螺絲</p>
<p>Ⓔ <b>Screw</b> × 4 螺絲</p>	<p>Ⓕ <b>Plastic Anchors</b> × 4 塑膠塞</p>	<p>Ⓖ <b>Hexagon Key</b> × 1 六角板手</p>	